

Wiring Guide

WD and HC series



The manual and quick start guide, can be found on our website:

www.clicglass.com



Step 1 — Find a suitable location for the electronics per the manual (i.e. Mechanical Room). Must have a wire path to the window of 100 meters (328 ft) or less, and access to 120VAC at the electronics location.

Step 2 — Run a minimum of 18-2 CL3 cable from the Glass Out of the controller to each glass panel.

Step 3 — Run a separate 18-2 CL3 cable to the desired user-control location for the CLiC panels or to the automation system if one is being used.

Notes:

- Leave sufficient wire at the window/door frame for final connections.
- Commercial applications require shielded wiring.